



Legend Series Reversible Instructions



1330 Pigeon Rd
Bad Axe, MI 48413
Toll Free: 866-712- 0606
Fax: 989-269-5902

www.global-poolproducts.com



1. Rotate Actuator

- a. Using a $\frac{3}{4}$ " wrench and a $\frac{3}{4}$ " socket on a ratchet, loosen the two bolts attaching the actuator to the lift
- b. Once loosened remove bolts taking care to not lose any spacers, nuts or bolts (taking a picture of how the spacers are oriented before removing them will help in reassembly later)
- c. Rotate actuator around so the ends are at the same points on the lift but the round extended portion of the actuator (that attaches to the base) is on the other side allowing the seat to clear in its load position.
- d. Install bolts with spacers in the same orientation and tighten back up



Rotate so this is on the opposite side of the seat



2. Swap leveling Bracket

- a. Loosen the nut holding the leveling bracket to the base and swap to the other side of the base, making sure the stud that goes through the seat tube bracket is facing away from the lift
- b. Swap the stud cover cap to the unused side and tighten the nut down to finish installing the leveling bracket



Make sure this is pointing out when installed on the correct side

Remove this nut and install all components on the other side

3. Seat Tube installation

- a. Install the seat tube the same as normal just from the opposite side and while installing line up and install the leveling bracket stud through the seat tube bracket and push all the way through.
- b. Once everything is lined up install a nut on the seat tube bolt and leveling bracket bolt and tighten both down.

4. Foot Rest

- a. Loosen the two bolts attaching the foot rest to the bracket and swap to the second set of holes
- b. Once aligned and bolts are through reinstall nuts and tighten them down.
- c. To install on lift slide foot rest bracket into the seat tube from the opposite side as normal and use the hole further from the edge of the tube to line up and install in seat tube.

Standard Setup how it ships



Align to the other bolt holes to configure like this
Use this bolt hole to install into seat tube

